Part 5 - Install Netbox

Installing the Netbox Server

In this section, there are steps for installing NetBox. For more detail about installing Netbox refer to the documentation - https://docs.netbox.dev/en/stable/

The steps to complete this section are:

- Update software
- Install required software
- Add custom repositories
- Download and configure PostgreSQL
- Create a Database
- Install and test Redis Server
- Configure and install NetBox service
- Configure Apache (web server)
- Connect to Web GUI
- Explore the NetBox service

To install the required files open a terminal window and ssh to the server that will be used to install Netbox.

```
ssh apnic@192.168.30.10
```

NOTE: Type yes if asked about wanting to continue connecting

Password = training

Confirm the version of Ubuntu.

lsb_release -a

NetBox requires Python version 3.8 and PostgreSQL version 11 and above. However Ubuntu 18.04 installs versions prior to these releases, whilst Ubuntu 20.04 installs the correct versions.

```
Update the software and install required software.
     sudo apt-get update && sudo apt-get -y dist-upgrade
Password =
               training
    Don't forget to use
                         sudo at the start of the commands if not running as root user.
Install required software
     sudo apt-get install -y git gcc redis python3-setuptools graphviz python3 \
     python3-pip python3-venv python3-dev build-essential \
     libxml2-dev libxslt1-dev libffi-dev libpq-dev libssl-dev zlib1g-dev
Confirm Python version.
     python3 -V
Install PostgreSQL. Netbox requires version 11 PostgreSQL, which is not available in the default Ubuntu software repository fro Ubuntu 18.04.
     sudo apt-get install -y postgresql libpq-dev
Create a database.
Connect with the newly set-up database, log into the postgres account and open a postgress prompt using the command:
     sudo -u postgres psql
Create a new database
     CREATE DATABASE netbox;
Create a new user.
     CREATE USER netbox WITH PASSWORD 'training';
Grant the new user the correct permissions
```

```
GRANT ALL PRIVILEGES ON DATABASE netbox TO netbox;
Exit postgreSQL
    \q
Install the Redis Server
    sudo apt install -y redis-server
    sudo systemctl start redis-server
    sudo systemctl enable redis-server
    sudo systemctl status redis-server
Check the service responds
    redis-cli ping
Clone the Ntebox git repository
    cd /opt
    sudo git clone -b master https://github.com/netbox-community/netbox.git
Create the netbox user and group
    sudo adduser --system --group netbox
    sudo chown --recursive netbox /opt/netbox/netbox/media/
Configure and install NetBox service.
Create a copy of the sample configuration file
    cd /opt/netbox/netbox/
    sudo cp configuration_example.py configuration.py
Update the allowed hosts and current database settings
    grep -in -A 11 "^allowed_hosts" configuration.py
    sudo sed -i "11s/\[\]/\['192.168.30.254','192.168.30.10','127.0.0.1'\]/" configuration.py
    sudo sed -i "17s/''/'netbox'/" configuration.py
    sudo sed -i "18s/''/'training'/" configuration.py
```

```
View the allowed hosts and current database settings
```

```
Generate the secret key and add to the configuration file
```

grep -in -A 11 "^allowed hosts" configuration.py

```
sudo sed -i "66s/''/'$(python3 /opt/netbox/netbox/generate_secret_key.py)'/" configuration.py
sudo sed -i "66s/''/\&/" configuration.py
grep -n "^SECRET_KEY" configuration.py
```

Install Netbox

```
sudo /opt/netbox/upgrade.sh
```

Create the Netbox user account. As NetBox doesnt create its user, we have to do it manually. Enter the python environment and use **apnic** as the user and **training** as the password.

```
source /opt/netbox/venv/bin/activate
python3 ../manage.py createsuperuser --username apnic --email group30@apnictraining.net
```

To exit the virtual environment type deactivate .

Setup the Gunicorn. For more detail refer to https://gunicorn.org

```
sudo cp /opt/netbox/contrib/gunicorn.py /opt/netbox/gunicorn.py
```

Update the listening address from 127.0.0.1 to 0.0.0.0

```
sudo sed -i 's/127.0.0.1/0.0.0.0/' /opt/netbox/gunicorn.py
```

Configure NetBox to start after a system reboot.

Copy the systemd files to the system directory

```
sudo cp -v /opt/netbox/contrib/*.service /etc/systemd/system/
sudo systemctl daemon-reload
```

Restart and check the NetBox services

```
sudo systemctl start netbox
sudo systemctl start netbox-rq
sudo systemctl enable netbox
sudo systemctl enable netbox-rq
sudo systemctl status netbox
```

Note: Press **q** to quit the status output

Configure the HTTP service

```
sudo apt install -y apache2
```

To avoid the complexity we will use the default configuration file. But make sure you modify the ServerName portion, and put # before the SSL configuration lines and change the default port from 443 to 80, as we are not using HTTPS in this LAB.

```
sudo cp /opt/netbox/contrib/apache.conf /etc/apache2/sites-available/netbox.conf
sudo sed -i 's/443/80/' /etc/apache2/sites-available/netbox.conf
sudo sed -i 's/netbox.example.com/192.168.30.10/' /etc/apache2/sites-available/netbox.conf
sudo sed -i 's/SSL/\#SSL/g' /etc/apache2/sites-available/netbox.conf
cat /etc/apache2/sites-available/netbox.conf
```

Enable the netbox site, and restart the apache service.

```
sudo a2enmod ssl proxy proxy_http headers
sudo a2ensite netbox
sudo systemctl restart apache2
```

Using a browser try to open http://192.168.30.10

You have reached the end of this lab.